

Installation Tank Lid with Hosetail to Float Valve 1"

For all Tank Lids with Ø 15 - 40cm internal and external thread

Scope of delivery:

- Hosetail
- Gasket Ring
- Drilled Tank Lid
- Float Valve 1"
- PTFE-tape



Installation:

1. Wrap the thread of the hosetail with PTFE-tape (about 6 wraps clockwise)
2. Put the gasket ring over the wrapped thread.
3. Slide the prepared hosetail with the gasket ring from the top of the lid through the drilled hole.
4. Screw the float valve onto the thread and tighten it hand-tight.
5. The lid with float valve is now ready to use.